

# NETASQ FIREWALL MULTIFUNCTION

## USER CONFIGURATION MANUAL

<b>Date</b>	<b>Version</b>	<b>Author</b>	<b>Details</b>
April 2012	V1.2 - Firmware V9.0.3	NETASQ	Update

Reference : naengde\_FirewallUserGuide.doc

<b>WELCOME</b>	<b>6</b>	<b>CERTIFICATES AND PKI</b>	<b>38</b>
<b>ACCESS PRIVILEGES</b>	<b>7</b>	<b>Possible operations</b>	<b>38</b>
<b>“Default options” tab</b>	<b>7</b>	Search bar	38
Authentication	7	Filter	38
SSL VPN	7	Add	38
IPSEC	7	Delete	39
<b>“User configuration” tab</b>	<b>8</b>	Download	39
Possible operations	8	LDAP publication	40
Configuration table	8	Create a CRL	40
<b>“PPTP” tab</b>	<b>9</b>	Check usage	40
<b>ACTIVE UPDATE</b>	<b>11</b>	<b>Adding authorities and certificates</b>	<b>41</b>
<b>Automatic updates</b>	<b>11</b>	<b>CLI CONSOLE</b>	<b>49</b>
<b>Update servers</b>	<b>11</b>	<b>List of commands</b>	<b>49</b>
<b>ADMINISTRATORS</b>	<b>12</b>	<b>Data entry zone</b>	<b>50</b>
<b>“Administrators” tab</b>	<b>12</b>	<b>CONFIGURATION</b>	<b>51</b>
Possible operations	12	<b>“General configuration” tab</b>	<b>51</b>
Table of privileges	13	General configuration	51
<b>“Administrator account” tab</b>	<b>15</b>	Time configuration	51
<b>ALARMS</b>	<b>16</b>	List of NTP servers	52
<b>View by inspection profile</b>	<b>16</b>	<b>“Firewall administration” tab</b>	<b>52</b>
Selecting the configuration profile	16	Access to the firewall’s administration interface	52
The various columns	17	Access to firewall administration pages	53
<b>View by context</b>	<b>17</b>	Remote SSH access	53
<b>ANTISPAM</b>	<b>19</b>	<b>“Network settings” tab</b>	<b>53</b>
<b>“General” tab</b>	<b>19</b>	Proxy server	53
SMTP parameters	19	Limits	53
Advanced properties	20	DNS resolution	54
<b>“Whitelisted domains” tab</b>	<b>21</b>	<b>DASHBOARD</b>	<b>55</b>
<b>“Blacklisted domains” tab</b>	<b>21</b>	<b>The module configuration menu</b>	<b>55</b>
<b>ANTIVIRUS</b>	<b>23</b>	My favorites	55
<b>Antivirus engine</b>	<b>23</b>	Configuration	55
<b>Parameters</b>	<b>23</b>	<b>The dynamic area: widgets</b>	<b>56</b>
Analysis of ClamAV files	23	Network	57
Analysis of Kaspersky files	23	Alarms	57
<b>AUTHENTICATION</b>	<b>24</b>	Resources	57
<b>Authentication wizard</b>	<b>24</b>	License	58
Authenticating on an Active Directory (Kerberos)	24	Hardware	58
Authenticating on the internal directory (LDAP)	25	Properties	58
Authenticating on a RADIUS base	27	Active Update	59
<b>“General” tab</b>	<b>28</b>	Services	59
Enabling the captive portal	28	Interfaces	59
Captive portal: SSL access	28	<b>DHCP</b>	<b>60</b>
Advanced properties	28	<b>The “General” tab</b>	<b>60</b>
<b>“Available methods” tab</b>	<b>29</b>	<b>“Server settings” tab</b>	<b>60</b>
Authentication methods	29	Advanced properties	61
Interfaces allowed	31	<b>“Address range” tab</b>	<b>61</b>
Redirection method for the HTTP proxy	32	<b>“Host” tab</b>	<b>62</b>
<b>“Internal interfaces” tab</b>	<b>32</b>	<b>“Relay settings” tab</b>	<b>62</b>
User passwords	32	Listening interfaces on the DHCP relay service	62
Authentication periods allowed	32	<b>DIRECTORY CONFIGURATION (LDAP)</b>	<b>63</b>
Advanced properties	33	<b>Creating an internal LDAP</b>	<b>63</b>
<b>“External interfaces” tab</b>	<b>34</b>	Step 1: Selecting the directory	63
User passwords	34	Step 2: Accessing the directory	63
Authentication periods allowed	34	Step 3: Authentication	64
Advanced properties	34	Internal LDAP directory screen	64
<b>BLOCK MESSAGES</b>	<b>36</b>	<b>Connecting to an external LDAP directory</b>	<b>66</b>
<b>Antivirus tab</b>	<b>36</b>	Step 1: Selecting the directory	66
POP3 protocol	36	Step 2: Accessing the directory	66
SMTP protocol	36	Step 3: Authentication	66
FTP protocol	37	External LDAP directory screen	67
<b>“HTTP block page” tab</b>	<b>37</b>	<b>“Structure” tab</b>	<b>68</b>
		<b>Connecting to a Microsoft Active Directory</b>	<b>69</b>
		Step 1: Selecting the directory	70

Step 2: Accessing the directory	70	Communication between firewalls in the high availability cluster	105
Step 3: Authentication	70	Advanced properties	105
Microsoft Active Directory screen	70	<b>IDENTIFICATION PORTAL</b>	<b>108</b>
“Structure” tab	72	Logging on	108
<b>DNS CACHE PROXY</b>	<b>74</b>	Logging off	109
<b>Enable DNS cache</b>	<b>74</b>	<b>IMPLICIT RULES</b>	<b>110</b>
List of clients allowed to used the DNS cache	74	<b>Implicit filter rules</b>	<b>110</b>
Advanced properties	75	Rule table	110
<b>DYNAMIC DNS</b>	<b>76</b>	<b>INSPECTION PROFILES</b>	<b>112</b>
<b>List of Dynamic DNS profiles</b>	<b>76</b>	<b>Security inspection</b>	<b>112</b>
<b>Configuring a profile</b>	<b>76</b>	Global configuration for each profile	112
DNS resolution	76	Configuring profiles	113
Dynamic DNS service provider	77	<b>IPSEC VPN</b>	<b>114</b>
Advanced properties	77	<b>“Encryption policy – Tunnels” tab</b>	<b>114</b>
<b>E-MAIL ALERTS</b>	<b>78</b>	Site to site (Gateway-Gateway)	115
<b>“Configuration” tab</b>	<b>78</b>	The table	116
Enable e-mail notifications	78	Anonymous – Mobile users	117
SMTP server	78	<b>“Peers” tab</b>	<b>119</b>
E-mail sending frequency (in minutes)	79	List of peers	119
Intrusion prevention alarms	79	Peer information	120
System events	79	<b>“Identification” tab</b>	<b>124</b>
<b>“Recipients” tab</b>	<b>80</b>	Approved certificate authorities	124
Creating a group	80	Mobile tunnels: pre-shared keys	124
Deleting a group	80	<b>“Encryption profiles” tab</b>	<b>125</b>
Check use	80	Default encryption profiles	125
<b>“Templates” tab</b>	<b>81</b>	<b>INTERFACES</b>	<b>128</b>
Editing the template (HTML)	81	<b>Operating mode between interfaces</b>	<b>128</b>
Vulnerability detection	81	Advanced mode	128
Certificate request	81	Bridge mode or transparent mode	129
User enrolment	81	Hybrid mode	129
List of variables	81	Conclusion	129
Example of a report received by e-mail regarding alarms	82	<b>Presentation of the configuration screen</b>	<b>129</b>
<b>ENROLMENT</b>	<b>83</b>	Directory of interfaces	130
<b>The enrolment table</b>	<b>83</b>	Toolbar	130
Possible operations	83	<b>Modifying a Bridge</b>	<b>131</b>
User enrolment and certificate requests	83	“General” tab	131
Advanced properties	84	“Advanced configuration” tab	132
<b>FILTERING AND NAT</b>	<b>85</b>	“Bridge members” tab	133
<b>Policies</b>	<b>85</b>	<b>Creating a bridge</b>	<b>133</b>
Selecting the filter policy	85	Identifying the bridge	133
Possible operations	86	Address range	134
Drag & drop	86	<b>Deleting a bridge</b>	<b>134</b>
<b>“Filtering” tab</b>	<b>86</b>	<b>Modifying an Ethernet interface (in bridge mode)</b>	<b>134</b>
Actions on filter policy rules	87	“Configuration of the interface” tab	135
Filter table	88	“Advanced configuration” tab	136
<b>“NAT” tab</b>	<b>96</b>	<b>Modifying an Ethernet interface (in advanced mode)</b>	<b>138</b>
Actions on NAT policy rules	96	<b>Modifying a VLAN</b>	<b>139</b>
NAT table	97	“Configuration of the interface” tab	139
<b>HIGH AVAILABILITY</b>	<b>102</b>	“Advanced configuration” tab	140
<b>Step 1: Creating or joining a high availability cluster</b>	<b>102</b>	<b>Creating a VLAN</b>	<b>142</b>
<b>Step 2: Configuring network interfaces</b>	<b>103</b>	Step 1	142
If you have chosen to create a cluster	103	Step 2: VLAN attached to a single interface (VLAN endpoint)	143
If you have chosen to join a cluster	103	Step 3: VLAN attached to 2 interfaces (crossing VLAN)	143
<b>Step 3: Cluster’s pre-shared key</b>	<b>104</b>	Step 4: VLAN attached to 2 interfaces (crossing VLAN)	144
If a cluster is being created	104	Step 5: VLAN attached to 2 interfaces (crossing VLAN)	145
If a cluster exists	104	Adding a VLAN	145
<b>Step 4: Summary</b>	<b>105</b>	<b>Deleting a VLAN</b>	<b>145</b>
If a cluster is being created	105		
If a cluster exists	105		
<b>High availability screen</b>	<b>105</b>		

<b>Modifying a modem</b>	<b>145</b>	<b>PROTOCOLS AND APPLICATIONS</b>	<b>173</b>
PPPoE modem	145	<b>Protocols</b>	<b>173</b>
PPTP Modem	146	Search	173
PPP Modem	147	List of protocols	173
<b>Creating a modem</b>	<b>148</b>	<b>Profiles</b>	<b>173</b>
Step 1	148	Selecting a profile	173
Step 2	149	Buttons	173
<b>Deleting a modem</b>	<b>149</b>	<b>HTTP</b>	<b>174</b>
<b>General remarks on configuring modems</b>	<b>149</b>	“IPS” tab	174
<b>LICENSE</b>	<b>151</b>	“Proxy” tab	176
<b>“General” tab</b>	<b>151</b>	“ICAP” tab	177
Buttons	151	“Analyzing files” tab	178
Dates	151	<b>SMTP</b>	<b>179</b>
Important information about the license	151	“IPS” tab	179
Installing from a file	152	“Proxy” tab	180
Advanced properties	152	“SMTP Commands” tab	181
<b>“License details” tab</b>	<b>153</b>	“Analyzing files” tab	182
Buttons	153	<b>POP3</b>	<b>182</b>
The table	153	“IPS - PROXY” tab	182
<b>LOGS- SYSLOG</b>	<b>157</b>	“POP3 Commands” tab	183
<b>“Local storage” tab</b>	<b>157</b>	“Analyzing files” tab	184
If the disk space quota is full	157	<b>FTP</b>	<b>184</b>
Configuration of the space reserved for logs	157	“IPS” tab	184
<b>“Syslog” tab</b>	<b>158</b>	“Proxy” tab	185
<b>MAINTENANCE</b>	<b>160</b>	“Commands” tab	186
<b>“Configuration” tab</b>	<b>160</b>	“Analyzing files” tab	187
System disk	160	<b>SSL</b>	<b>187</b>
Maintenance	160	“IPS” tab	187
System report (sysinfo)	160	“Proxy” tab	188
<b>“Backup” tab</b>	<b>161</b>	<b>TCP-UDP</b>	<b>190</b>
Configuration backup	161	Profiles screen	190
Advanced properties	161	Global configuration screen	191
<b>“Restore” tab</b>	<b>161</b>	<b>IP</b>	<b>192</b>
Password	161	<b>ICMP</b>	<b>193</b>
Advanced properties	161	<b>DNS</b>	<b>193</b>
<b>“Secure configuration” tab</b>	<b>162</b>	<b>Yahoo Messenger (YMSG)</b>	<b>194</b>
Secure configuration	162	<b>ICQ – AOL IM (OSCAR)</b>	<b>194</b>
Restore from the USB key	162	<b>Live Messenger (MSN)</b>	<b>195</b>
<b>“System update” tab</b>	<b>162</b>	<b>TFTP</b>	<b>195</b>
Advanced properties	163	<b>NetBios CIFS</b>	<b>196</b>
<b>NETWORK OBJECTS</b>	<b>164</b>	<b>NetBios SSN</b>	<b>196</b>
<b>Possible actions</b>	<b>164</b>	<b>MGCP</b>	<b>197</b>
Filter	164	<b>RTP</b>	<b>197</b>
<b>The different types of objects</b>	<b>165</b>	<b>RTCP</b>	<b>198</b>
Host	165	<b>SIP</b>	<b>198</b>
Network	165	SIP Commands	199
IP address range	166	<b>Others</b>	<b>201</b>
Port – port range	166	<b>QUALITY OF SERVICE (QoS)</b>	<b>202</b>
IP protocol	166	<b>Network traffic</b>	<b>202</b>
Group	167	<b>Bandwidth reservation or limitation (CBQ)</b>	<b>202</b>
Port group	167	<b>Queues</b>	<b>203</b>
<b>PPTP SERVER</b>	<b>169</b>	Class-based queue (CBQ)	203
<b>General configuration</b>	<b>169</b>	Monitoring queue	204
Parameters sent to PPTP clients	169	Priority queue	205
<b>Advanced properties</b>	<b>169</b>	Available queues	206
Traffic encryption	170	<b>Examples of application and usage recommendations</b>	<b>206</b>
<b>PREFERENCES</b>	<b>171</b>	<b>ROUTING</b>	<b>209</b>
Access NETASQ’s website	171	<b>“Gateway” tab</b>	<b>209</b>
Connection settings	171	Advanced configuration	209
Application settings	171	Sending the configuration	211
Management interface behavior	172	<b>“Static route” tab</b>	<b>211</b>
External links	172	Button bar	211
		Presentation of the table	212

<b>SMTP FILTERING</b>	<b>213</b>		
<b>Profiles</b>	<b>213</b>		
Selecting a profile	213		
Buttons	213		
<b>Rules</b>	<b>214</b>		
Possible operations	214		
Table	214		
Errors found in the SMTP filter policy	215		
<b>SNMP AGENT</b>	<b>216</b>		
<b>“General” tab</b>	<b>216</b>		
Configuration of MIB-II information	216		
Sending of SNMP alerts (traps)	217		
<b>“SNMPv3” tab</b>	<b>217</b>		
Connection to the SNMP agent	217		
Authentication	217		
Encryption (optional)	217		
Sending of SNMPv3 alerts (traps)	217		
<b>“SNMPv1 - SNMPv2c” tab</b>	<b>218</b>		
Connection to the SNMP agent	218		
Sending of SNMPv2c alerts (traps)	219		
Sending of SNMPv1 alerts (traps)	219		
<b>MIBS and Traps SNMP</b>	<b>219</b>		
NETASQ SNMP event and alert (traps) format	219		
Management information bases (MIBs)	221		
<b>SSL FILTERING</b>	<b>231</b>		
<b>Profiles</b>	<b>231</b>		
Selecting a profile	231		
<b>Rules</b>	<b>232</b>		
Possible operations	232		
Table	232		
Errors found in the SSL filter policy	232		
<b>SSL VPN</b>	<b>232</b>		
<b>“General” tab</b>	<b>233</b>		
Advanced properties	234		
<b>“Web servers” tab</b>	<b>234</b>		
Adding a web server	235		
Adding an OWA web server	236		
Adding a Lotus Domino web server	237		
<b>“Application servers” tab</b>	<b>238</b>		
Configuration with an application server	238		
Configuration with a Citrix server	238		
<b>Deleting a server</b>	<b>239</b>		
<b>“User profiles” tab</b>	<b>239</b>		
Operating principle	239		
Configuring a profile	239		
<b>SSL VPN services on the NETASQ web portal</b>	<b>240</b>		
Accessing your company’s web sites via an SSL tunnel	241		
<b>SYSTEM EVENTS</b>	<b>242</b>		
<b>Possible actions</b>	<b>242</b>		
Search	242		
Restore the default configuration	242		
<b>List of events</b>	<b>242</b>		
<b>TIME OBJECTS</b>	<b>244</b>		
<b>Possible actions</b>	<b>244</b>		
<b>Information regarding objects</b>	<b>244</b>		
Fixed event	245		
Day of the year	245		
Day(s) of the week	245		
Time slots	245		
<b>URL FILTERING</b>	<b>246</b>		
<b>Profiles</b>	<b>246</b>		
Selecting a profile	246		
Buttons	246		
<b>Rules</b>	<b>247</b>		
Possible operations	247		
Table	247		
Errors detected	247		
<b>USERS</b>	<b>248</b>		
<b>Possible operations</b>	<b>248</b>		
Search bar	248		
Filter	248		
Creating a group	248		
Creating a user	249		
Delete	249		
Check usage	250		
<b>List of users (CN)</b>	<b>250</b>		
“Account” tab	250		
“Certificate” tab	250		
“Member of these groups” tab	250		
<b>VULNERABILITY MANAGEMENT</b>	<b>252</b>		
<b>General configuration</b>	<b>252</b>		
List of monitored network objects	253		
<b>Advanced properties</b>	<b>254</b>		
Exclusion list (unmonitored objects)	254		
<b>WEB OBJECTS</b>	<b>255</b>		
<b>“URL” tab</b>	<b>255</b>		
URL group table	255		
URL table (“URL group: All”)	256		
<b>“Certificate name (CN)” tab</b>	<b>256</b>		
<b>“URL database” tab</b>	<b>257</b>		
<b>GLOSSARY</b>	<b>258</b>		
<b>A</b>	<b>258</b>		
<b>B</b>	<b>260</b>		
<b>C</b>	<b>261</b>		
<b>D</b>	<b>262</b>		
<b>E</b>	<b>263</b>		
<b>F</b>	<b>264</b>		
<b>G</b>	<b>264</b>		
<b>H</b>	<b>265</b>		
<b>I</b>	<b>266</b>		
<b>K</b>	<b>267</b>		
<b>L</b>	<b>267</b>		
<b>M</b>	<b>267</b>		
<b>N</b>	<b>268</b>		
<b>O</b>	<b>269</b>		
<b>P</b>	<b>269</b>		
<b>Q</b>	<b>272</b>		
<b>R</b>	<b>272</b>		
<b>S</b>	<b>273</b>		
<b>T</b>	<b>274</b>		
<b>U</b>	<b>275</b>		
<b>V</b>	<b>275</b>		
<b>W</b>	<b>276</b>		











































































































































































































































































































**Limit**

<b>Conn</b>	Maximum number of connections passing through ASQ. (Default value: 0 (=unlimited)).
<b>Network</b>	Maximum number of networks managed by ASQ. (Default value: 0 (=unlimited)).
<b>User</b>	Maximum number of users who can authenticate on the appliance. (Default value: 0 (=unlimited)).

**Network**

<b>HADialup</b>	Enables or disables the possibility of using dialups to establish high availability links. (Default value: 1).
<b>HybridMode</b>	Enables or disables hybrid mode on interfaces (mix of interfaces, bridges, VLANs, etc). (Default value: 1*).
<b>InterfaceRoute</b>	Allows routing by interface. This option is enabled by default. See the Menu: Configuration→Network→Interfaces/ Advanced properties tab/ Bridge: routing by interface” (Default value: 1).
<b>LBDialup</b>	Enables or disables load-balancing on dialups. (Default value: 1).
<b>QoS</b>	Enables or disables QoS. (Default value: 1).
<b>VLAN</b>	Enables or disables VLANs (Default value: 1).

**Proxy**

<b>Antispam</b>	Enables or disables spam filtering via DNSRBL in the proxy. (Default value: 1).
<b>Antivirus</b>	Enables or disables the ClamAV antivirus in the proxy. (Default value: 1).
<b>FTPProxy</b>	Enables or disables the FTP proxy. (Default value: 1**).
<b>HTTPProxy</b>	Enables or disables the http proxy (Default value: 1).
<b>ICAPURL</b>	Enables or disables the ICAP ReqMod. (Default value: 1).
<b>ICAPVirus</b>	Enables or disables the ICAP RespMod. (Default value: 1).
<b>IMAPProxy</b>	Enables or disables the IMAP proxy (which does not exist on UTMs). (Default value: 1).
<b>POP3Proxy</b>	Enables or disables the POP3 proxy. (Default value: 1).
<b>SMTPProxy</b>	Enables or disables the SMTP proxy. (Default value: 1).
<b>SpamVendor</b>	Enables or disables the spam filter heuristic engine. (Default value: 0).
<b>URLFiltering</b>	Enables or disables URL filtering via NETASQ’s database in the proxy. (Default value: 1).
<b>URLVendor</b>	Enables or disables URL filtering via Optenet’s database in the proxy. (Default value: 0).
<b>VirusVendor</b>	Enables or disables the Kaspersky antivirus in the proxy. (Default value: 0).



































































































































































































































**Man-in-the-middle attack**

Also known as a "replay attack", this consists of a security breach in which information is stored without the user's authorization and retransmitted, giving the receiver the impression that he is participating in an authorized operation. As a result of this, an attacker can intercept keys and replace them with his own without the legitimate parties' knowledge that they are communicating with an attacker in the middle.

**MAP**

This translation type allows converting an IP address (or n IP addresses) into another (or n IP addresses) when going through the firewall, regardless of the connection source.

**Modularity**

Term describing a system that has been divided into smaller subsystems which interact with each other.

**MSS (*Maximum Segment Size*)**

MSS value represents the largest amount of data (in bytes) that a host or any other communication device can contain in a single unfragmented frame. To get the best yield possible, the size of the data segment and the header have to be lower than the MTU.

---

**N**

---

**NAT (*Network address Translation*)**

Mechanism situated on a router that allows matching internal IP addresses (which are not unique and are often unroutable) from one domain to a set of unique and routable external addresses. This helps to deal with the shortage of IPv4 addresses on the internet as the IPv6 protocol has a larger addressing capacity.

**NETASQ EVENT REPORTER**

Module in NETASQ's Administration Suite that allows viewing log information generated by firewalls.

**NETASQ REAL-TIME MONITOR**

Module in NETASQ's Administration Suite that allows viewing the firewall's activity in real time.

**NETASQ Shield**

Security agent that protects Microsoft Windows® workstations and servers by integrating NETASQ's ASQ technology.

**NETASQ UNIFIED MANAGER**

Module in NETASQ's Administration Suite that allows configuring firewalls.



















